

SEAT SENSOR / SITZPLATZSENSOR

Description

The seat sensor enables contactless switching on/off of the infrared heater by sitting in front of the user

Innovative technology:

- slim and simple design
- easy construction
- contactless using
- optical lens
- compact detection area
- Compatible with Infrabox and Infrabox Basic



Details:

Item number	1-030-585
	IRB-F-S
Colour	black
Dimensions (WxHxD) [mm]	28 x 17.2 x 8.4
Interior mounting	Yes
Ambient temperature	0 - 50°C
Detection range [mm]	10 - 300
Cable length [m]	1,0
Supply voltage [V]	24



Mounting back rest




Mounting bench




SEAT SENSOR / SITZPLATZSENSOR

Dimensions



Wiring diagrams



1 Connection Seat sensor



SEAT SENSOR / SITZPLATZSENSOR

Beschreibung

Der Sitzplatzsensor ermöglicht ein kontaktloses Ein-/ Ausschalten des Infrarot-Strahlers durch davorsetzen des Benutzers

Innovative Technik:

- schlankes und einfaches Design
- einfache Montage
- kontaktlose Bedienung
- optische Linse
- kompakter Erfassungsbereich
- Kompatibel mit Infrabox und Infrabox Basic

**Details:**

Artikel Nummer	1-030-585
	IRB-F-S
Farbe	schwarz
Abmessungen (WxHxD) [mm]	28 x 17.2 x 8.4
Inneneinbau	Ja
Betriebstemperatur	0 - 50°C
Erfassungsbereich [mm]	10 - 300
Kabellänge [m]	1,0
Versorgungsspannung [V]	24



Montage Rückenlehne




Montage Bank



SEAT SENSOR / SITZPLATZSENSOR

Abmessungen



Anschlussplan

